

TOUCH SCREEN - Displays all the available features and general machine information

CLEAR ALL - Resets features to their default settings

PAUSE - Interrupts current job

START - Starts the job



MACHINE STATUS: Displays machine information



JOB STATUS: Displays the job queue information



FEATURES: Displays the job features on the screen

Features* are accessible by touching the tabs or All Services,  for example:

*Some features may not be available on your model.

LOAD PAPER

FAX

E-MAIL

COPY

LOAD PAPER

- Open the required paper tray.
- Load the paper, do not load above the maximum fill line.
- Adjust the guides to touch the edge of the paper.
- Close the paper tray, except the Bypass Tray.
- Confirm the paper size/type settings on the user interface.

QUICK FAX

- Load the original face up in the document handler.
- Touch the FAX or INTERNET FAX tab.
- Touch the screen buttons to make feature selections.
- Enter the receiving fax number using the keypad or select an e-mail address from the ADDRESS BOOK.
- Press START.

QUICK E-MAIL


- Load the original face up in the document handler.
- Touch the E-MAIL tab.
- Touch the screen buttons to make feature selections.
- Make a selection from the ADDRESS BOOK.
- Press START.

QUICK COPY

- Load the original face up in the document handler.
- Touch the COPY tab.
- Touch the screen buttons to make feature selections.
- Press START.

How to save a job for Reprint


1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. MAKE COPIES AND SAVE

Features Button




Press the **Features** button to display the features selection screen.

All Services Button




Select the **All Services** button **OR** the **Save Job for Reprint** tab.

Save Job for Reprint Button




Select the **Save Job for Reprint** button. If you cannot see the Save Job for Reprint button, select the **More Service** button first.

Quantity of Copies




Use the **numeric keypad** to enter the quantity of copies to be made.

Job Name




Select the **New Job Name** button. and input a unique and meaningful name for your saved job.

Destination Folder



Select the **Save Only** or **Copy and Save** button. From the folder list, select a **folder** as the destination for your saved job.

4. START THE JOB



Press the Start button to start your job.

That completes the procedure.


MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to send an Internet Fax

1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. ENTER INTERNET FAX OPTIONS

Features Button




Press the **Features** button to display the features selection screen.

All Services Button




Select the **All Services** button **OR** the **Internet Fax** tab.

Internet Fax Button



Select the **Internet Fax** button. If you cannot see the Internet Fax button, select the **More Service** button first.

E-mail Address



Select **To:** in the send field and either input the **full E-mail** address **OR** use the **address book** to select a recipient.

4. TRANSMIT THE INTERNET FAX



Press the Start button to start your job.

That completes the procedure.


MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to Scan to E-mail


1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.



Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. SELECT E-MAIL RECIPIENTS

Features Button



Press the **Features** button to display the features selection screen.

All Services Button



Select the **All Services** button **OR** the **E-mail** tab.


E-mail Button



Select the **E-mail** button. If you cannot see the E-mail button, select the **More Service** button first.




E-mail Address



Select **To:** in the send field and either input the **full E-mail address** **OR** use the **address book** to select a recipient.

4. SEND THE E-MAIL



Press the Start button to start your job.


That completes the procedure.

MORE INFORMATION

- For more information, please refer to:
- **Interactive User Guide CD 2**
 - **Quick Use Guide**
 - <http://www.xerox.com/support>

How to send a Fax (Server)

1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. ENTER FAX OPTIONS

Features Button



Press the **Features** button to display the features selection screen.

All Services Button



Select the **All Services** button **OR** the **Basic Faxing** tab.


Fax Button



Select the **Fax** button. If you cannot see the Fax button, select the **More Service** button first.




Fax Number



Use the **numeric keypad** to enter the recipient's fax number **OR** use the send list to select a previously stored number.

4. TRANSMIT THE FAX



Press the Start button to start your job.

That completes the procedure.


MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to Scan a document

1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. STORE THE SCANNED IMAGE

Features Button



Press the **Features** button to display the features selection screen.

All Services Button




Select the **All Services** button **OR** the **Network Scanning** tab.

Network Scanning Button




Select the **Network Scanning** button. If you cannot see the Network Scanning button, select the **More Service** button first.

Scanning Destination



From the **Template Destination** list, select the **template** that contains the **destination** for your scan job. The available Network, Scan to Mailbox and Scan to Home templates are all shown in the Template Destination list.

4. START THE JOB



Press the Start button to start your job.

That completes the procedure.


MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to send a Fax (Embedded)

1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. ENTER FAX OPTIONS

Features Button



Press the **Features** button to display the features selection screen.

All Services Button



Select the **All Services** button **OR** the **Basic Faxing** tab.


Fax Button



Select the **Fax** button. If you cannot see the Fax button, select the **More Service** button first.




Fax Number



Use the **numeric keypad** to enter the recipient's fax number **OR** use the send list to select a previously stored number.

4. TRANSMIT THE FAX



Press the Start button to start your job.

That completes the procedure.


MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to make a Copy


1. PREPARATION



Cancel any selections made by a previous user by pressing the **AC (Clear All)** button.


Remove any staples and paper clips from your documents and ensure that the documents are in good condition.

2. LOAD THE DOCUMENTS



Place the documents in the Document Handler in order (1,2,3...) with page 1 face up on top.

Slide the document guides against the front and rear edges of the documents.




OR

Place the document face down on the Document Glass and register it to the rear right corner.


3. MAKE COPIES

Features Button



Press the **Features** button to display the features selection screen.

All Services Button



Select the **All Services** button **OR** the **Basic Copying** tab.


Basic Copying Button



Select the **Copy** button. If you cannot see the Copy button, select the **More Service** button first.




Quantity of Copies



Use the **numeric keypad** to enter the quantity of copies to be made.

4. START THE JOB



Press the Start button to start your job.

That completes the procedure.

MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>

How to Load paper


1. OPEN THE PAPER TRAY



The Bypass Tray can be adjusted for all stock types and sizes between **A6** and **A3**.

Paper Trays 1 and 2 are **fully adjustable** for all stock sizes between **A5** and **A3**.

Paper Trays 3 and 4 are **dedicated** to hold either **A4** or **8.5"x11"**.




Paper tray 5 is a **high capacity** paper source **dedicated** to hold either **A4** or **8.5"x11"**.

Paper tray 5 is opened by accessing the door on the left hand side.


To open paper tray 5 press the button on the top of the tray.

Paper tray 5 automatically lowers.

2. LOAD THE PAPER





Do Not load paper above the **Maximum Fill line**.



For the Bypass Tray, and Paper Trays 1 and 2 **adjust the guides** to just touch the edge of the paper stack.

Close the Paper Tray

3. CONFIRM THE PAPER STOCK LOADED



For the Bypass Tray and Paper Trays 1 and 2, select the **Confirm** button **OR** select the **Change Size** and / or the **Change Type and Colour** buttons to reprogramme the tray if the paper size, type or

4. MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**


- **Quick Use Guide**

- <http://www.xerox.com/support>

How to Reprint a saved job


1. RETRIEVE THE SAVED JOB

Features Button




Press the **Features** button to display the features selection screen.

All Services Button



Select the **All Services** button **OR** the **Reprint Saved Jobs** tab.


Reprint Saved Job Button



Select the **Reprint Saved Job** button. If you cannot see the Reprint Saved Job button, select the **More Services** button first.




Select the Job



From the Job Name list, select the job to be reprinted


Select the Folder



From the Folder Name list, select the folder that contains the job you want to reprint.


2. AMEND SETTINGS AND PRINT QUANTITY

Basic Settings




If required, change the basic setting of the saved job from the **Basic Settings** tab.

Quantity of Prints



Use the **numeric keypad** to enter the quantity of reprints to be made.

3. START THE JOB



Select the **Print** or **Print and Save** button to start your job. That completes the procedure.

MORE INFORMATION

For more information, please refer to:

- **Interactive User Guide CD 2**
- **Quick Use Guide**
- <http://www.xerox.com/support>