Xerox® WorkCentre® 3045
Multifunction Printer

Menus





Display job status*

Enter the system menu

Access the address book*

Arrow buttons scroll up, down, forward, and back through the menus

OK button accepts the menu selection

Back/Return button goes up one level in the menu

System

Information Pages

- System Settings
- Panel Settings
- Job History
- Error History
- Demo Page
- Protocol Monitor*
- Address Book*
- Fax Activity*

Billing Meters

- Total Impression

Admin Menu

- Fax Book* ▶
  - Speed Dial
  - Group Dial
- Network* ▶
  - Ethernet†
  - Status**
  - Wireless Setup**
  - Reset Wireless**
  - TCP/IP
  - Protocol
  - Initialize NVM
- Fax Settings* ▶
  - Ans Select
  - Auto Answer Fax
  - Auto Ans.Tel/FAX
  - Auto Ans. Ans/FAX
  - ⬇
  - Ring Tone Volume
  - ⬇
  - Junk Fax Filter
  - ⬇
  - DRPD Pattern
  - ⬇
  - Discard Size
  - ECM
  - ⬇
  - Modem Speed
  - Fax Activity
  - ⬇
  - Region
- System Setup ▶
  - Power Saver Timer
  - Auto Reset
  - Fault time-Out
  - Job Time-Out
  - Clock Settings*
  - Alert tone
  - mm/inch
  - Low toner Alert
  - Power On Wizard
- Maintenance ▶
  - F/W Version
  - Adjust BTR
  - Adjust Fusing Unit
  - Density Adjustment
  - Clean Developer
  - Toner Refresh
  - Initialize NVM
  - Adjust Altitude
- Secure Settings ▶
  - Panel Lock
  - Service Lock
  - Secure Receive*
- Scan to Email* ▶
  - Edit From Field
- USB Setup ▶
  - Port Status

Defaults Settings

- Copy Defaults
- Scan Defaults
- Fax Defaults*
- Print from USB Defaults

Tray Settings

- Main Tray

Panel Language

English	Svenska
Français	Polski
Italiano	Türkçe
Deutsch	Русский
Español	Česko
Nederlands	Magyar
Dansk	Português Brasileiro



www.xerox.com/office/WC3045docs

⬇ = Additional items not shown
* WorkCentre 3045NI
** Wireless connection
† Ethernet connection

© 2011 Xerox Corporation. All rights reserved.
XEROX® and XEROX and Design® are trademarks of Xerox Corporation in the United States and/or other countries.