Readme.txt 29/04/2010

Xerox ColorQube(TM) 9201-9203 Utilities
version 50.00.0010
Copyright (C) 2010 Xerox Ltd.
All Rights Reserved

Table of Contents:

=========

- 1. Description
- 2. Features
- 3. System Requirements
- 4. Distribution
- 5. Installation
- 6. Further Help

1. Description

==========

The Xerox ColorQube(TM) 9201-9203 Utilities consists of a suite of tools for performing administrative tasks on the Xerox ColorQube(TM) 9201-9203 family of products.

All the tools connect to the device using a Universal Serial Bus (USB) connection.

2. Features

========

Fax Data Save/Restore - A tool for downloading/uploading fax phonebook data and backing up fax configuration data.

3. System Requirements

The following minimum configuration is required:

- An IBM Compatible PC running Windows XP (>=SP2), Vista, XP \times 64, Vista \times 64 or Windows 7
- A Type A USB port
- A USB A-B cable for connecting PC to device
- A CD-ROM drive or internet connection
- Internet Explorer v4.01 or later

Following installation see the individual help files for additional tool specific requirements.

4. Distribution

==========

This product contains the following key files:

Readme.txt - Introductory information (this file)

Setup.exe - Xerox ColorQube(TM) 9201-9203 Utilities setup

application

XeroxServicePort.inf - USB Driver inf file

5. Installation

5.1 Upgrading from a previous version

Readme.txt 29/04/2010

Remove the Xerox ColorOube(TM) 9201-9203 Utilities

This can be achieved using the Add/Remove program applet within the Windows Control Panel. The application Xerox ColorQube(TM) 9201-9203 Utilities should be removed. For Assistance, see Windows Help.

Run Xerox ColorQube(TM) 9201-9203 Utilities setup

Select Run from the Taskbar Start menu, type the full name of the setup file

(for example, $C:\download\setup.exe$), and press the Enter key. This will start

the setup application. Follow the prompts and online help to install.

5.2 New Installation

Run Xerox ColorQube(TM) 9201-9203 Utilities setup

Select Run from the Taskbar Start menu, type the full name of the setup file

(for example, $C:\download\$ etup.exe), and press the Enter key. This will start

the setup application. Follow the prompts and online help to install.

Install the USB Driver

Power up the device, connect the USB cable between the PC and device. The USB connection on the device is located at the rear top half. Windows will

detect the presence of a new USB device and request a driver. Browse to and

select XeroxServicePort.inf. The driver is now installed.

6. Further Help

For help with using the tools, please see the tools corresponding help file.