

Fig. 1  
**Top left cover**  
Gently open the top left cover while lifting up the release lever.




Fig. 3  
If you cannot remove jammed paper, then inside the fuser unit, lift up the green lever and remove the jammed paper.



Fig. 5  
Remove the jammed paper.




Fig. 2  
If the edge of the jammed paper can be reached at the output tray, pull the jammed paper in the direction of the feed-out area.



Fig. 4  
**Duplex Module Cover**  
Open the tray 5 (Bypass) and gently open the duplex module cover.



Fig. 6  
**Tray 5 (Bypass)**  
Inspect the inside (paper feed entrance) of Tray 5 (Bypass), and remove any jammed paper.





Fig. 7  
**Duplex Module Cover**  
 Remove the jammed paper.




Fig. 8  
**Bottom left cover**  
 Remove the jammed paper.



Fig. 9  
**Paper Tray 1 to 4**  
 Remove the jammed paper.

## Quick Start Guide

### Removing Paper Jam



**DocuColor 2240/1632**

THE DOCUMENT COMPANY

**XEROX**