



Xerox® Phaser® 6700

Replace Hard Drive • Remplacer le disque dur • Sostituire il disco rigido • Festplatte austauschen
 Sustituir la unidad de disco duro • Substituir unidade de disco rígido • Vaste schijf vervangen • Byta hårddisk • Bytte harddisk
 Udskift harddisk • Vaihda kiintolevy • Замена жесткого диска • Vyměňte pevný disk • Wymień twardy dysk
 Merevlemez-meghajtó visszahelyezése • Sabit Diski Değiştirme • Αντικατάσταση σκληρού δίσκου • 更换硬盘 • 更換硬碟
 하드 드라이브 교체


1




2



3




4




5

5



6



7

Confirm installation

Confirmez l'installation
 Confermare l'installazione
 Installation bestätigen
 Confirmar instalaci3n
 Confirmar instalaç3o
 Installatie bevestigen
 Bekr3fta installation
 Bekreft montering
 Bekr3fte installation
 Vahvista asennus
 Подтвердите установку
 Potvrdit instalaci
 Potwierdź instalację
 Telepit3s j3nv3hagy3sa
 Y3klemeyi Onayla
 Επιβεβαίωση εγκατάστασης
 确认安装
 確認安裝
 설치 확인

Print Configuration Report

Imprimez le relev3 de configuration
 Stampa rapporto di configurazione
 Konfigurationsbericht drucken
 Imprimir informe de configuraci3n
 Imprimir relat3rio de configuraç3o
 Configuratie-overzicht afdrukken
 Configuratie-overzicht afdrukken
 Skriv ut konfigurationsrapport
 Skriv ut konfigurasjonsrapport
 Udskriv konfigurationsside
 Tulosta konfiguointiraportti
 Печать отчета о конфигурации
 Tisk sestavy konfigurace
 Drukuj raport konfiguracji
 Nyomtat3skonfigur3ci3s jelent3s
 Yapılandırma Raporunu Yazdır
 K3rta Secure Digital (SD)
 打印配置报表
 列印設定頁
 구성 보고서 인쇄

