







1




2




3




4



5




6




2


7




8




9




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28




29




30




31




32



33



34





[www.support.xerox.com](http://www.support.xerox.com)