## THE DOCUMENT COMPANY XEROX

#### DC230LP Windows NT® 4.0 NetBIOS/NetBEUI Quick Install

#### **Installation Requirements:**

If this is a Token Ring installation, the Token Ring card must be installed by your Xerox service representative and configured before performing this procedure. Refer to the *Token Ring Quick Install* card.

#### **Before Installation:**

Record the following information for use during setup at the DC230LP.

Host Name: \_\_\_\_\_

Workgroup: \_\_\_

This installation procedure assumes that you know how to navigate through the menu system on the DC230LP Control Panel. Refer to the quick reference card, *Using the Menu System*, (701P96834) for assistance.

- Connect the DC230LP to your network outlet or cable.
- 2. Access the System Administration menus:
  - a) Press [Online] to take the printer off line.

    Printer Off Line displays.
  - b) Press [Menu]. Main Menu > displays.

c) Press [▶], then press [▲] or [▼] until.

System > displays.

- d) Press [▶]. Enter Password > displays.
- e) Use the [▲] and [▶] keys to enter [2222].

**Note:** 2222 is the factory default password and may be changed to suit your needs. Refer to the DC230LP System Administration Guide, Network Installation and Troubleshooting.

- f) Press [Enter]. System Admin > displays.
- 3. Access the NetBIOS/NetBEUI menus:
  - a) Press [▶]. Port Setup > displays.
  - b) Press [▼] until Network Setup > displays.
  - c) Press [▶]. TCP/IP > displays.
  - d) Press [▼] until displays.

**4.** Enable NetBIOS/NetBEUI:

- a) Press [▶]. Enablement bisabled displays.
- b) Press [▶]. Enablement = displays.
- c) Press [▼]. Enablement = displays.
- d) Press [Enter]. \*\*SAVED\*\* displays momentarily, followed by
  Enablement > .
- Select the appropriate interface for your network:

**Note:** Token Ring will not be available as a selection unless it has been installed and configured.

- a) Press [▼] until Interface Ethernet

  displays. If Ethernet is the desired interface, go to step 6.

# THE DOCUMENT COMPANY XEROX

### DC230LP Windows NT® NetBIOS/NetBEUI Quick Install

c) Press [Enter]. \*\*SAVED\*\* displays momentarily, followed by



- **6.** Enter the Host Name:
  - a) Press [▼] until Host Name / (current entry)
     displays.
  - b) Press [ ]. Host Name (current entry) displays.
  - c) Press [▶] repeatedly until the cursor reaches the end of the entry. A tone sounds indicating when the last character has been reached.
  - d) Press [◀] repeatedly to delete the current entry.
  - e) Use the [▲] or [▼] key to enter the first character of the Host Name.
  - f) Press [>] to move to the next character. Repeat this procedure to enter the entire Host name.
  - g) Press [Enter]. \*\*SAVED\*\* displays momentarily, followed by



- 7. Enter the Printer Name:
  - a) Press [▼] until Printer Name (current entry) > displays.
  - b) Press [►]. Printer Name (current entry) displays.
  - c) Press [▶] repeatedly until the cursor reaches the end of the entry. A tone sounds indicating when the last character has been reached.
  - d) Press [◄] repeatedly to delete the current entry.
  - e) Use the [▲] or [▼] key to select the first character in the Printer Name.
  - f) Press [▶] to move to the next character. Repeat procedure to enter entire Printer Name.
  - g) Press [Enter]. \*\*SAVED\*\* displays momentarily, followed by



- 8. Enter the Workgroup name:
  - a) Press [▼] until Workgroup / (current entry) > displays.
  - b) Press [▶]. Workgroup displays.
  - c) Press [►] repeatedly until the cursor reaches the end of the display. A tone sounds indicating when the last character has been reached.
  - d) Press [◄] repeatedly to delete the current entry.
  - e) Use the [▲] or [▼] key to select the first character in the Workgroup name.
  - f) Press [▶] to move to the next character. Repeat this procedure to enter the entire Workgroup name.
  - g) Press [Enter]. \*\*SAVED\*\* displays momentarily, followed by



## THE DOCUMENT COMPANY XEROX

#### DC230LP Windows NT® 4.0 NetBIOS/NetBEUI Quick Install

- **9.** Save all settings:
  - a) Press [Online]. Reset Required Press ENTER key displays.
  - b) Press [Enter]. Please Wait... displays.

    The DC230LP will reboot, save the settings entered, and print a Configuration Report in approximately 3 minutes.
- 10. Check the settings on the configuration sheet against those that were entered to be sure they are correct.
- 11. At the client, install print drivers and map the printer in the usual manner. Refer to the CentreWare® manual, Getting Started with Print and Fax Services, for additional information.

Additional information on the Windows NT NetBIOS/NetBEUI setup can be found in the DC230LP System Administration Guide, Network Installation and Troubleshooting.

# THE DOCUMENT COMPANY XEROX

### DC230LP Windows NT® 4.0 NetBIOS/NetBEUI Quick Install

