



















xerox®

3-Tray Option • Option 3 magasins • Opzione a 3 vassoi • Konfiguration mit 3 Behältern • Opción de 3 bandejas  
Opció de 3 safates • Opção bandeja 3 • Optie met 3 laden • 3 magasin (tillval) • Alternativ med tre magasiner  
3 magasiner (tilvalg) • 3 alustaa • Три дополнительных лотка • Volitelný modul se 3 zásobníky • Opcja 3 tacy  
Háromtálcsás opció • Optiunea 3 tăvi • 3 Kasetli Seçenek • Επιλογή 3 δίσκων












**13**



**13.1**



**13.2**



**14**

