



15mm

20mm



- ! Error | French Error | Italian Error | German Error | Spanish Error | British Portuguese Error
- Manual-Feed | Alimentation manuelle | Alimentazione manuale | Manuelle Zuführung | Alimentación manual | Alimentação manual
- Paper | Papier | Carta | Papier | Papel | Papel
- Data | French Data | Italian Data | German Data | Spanish Data | British Portuguese Data
- Cancel | French Cancel | Italian Cancel | German Cancel | Spanish Cancel | British Portuguese Cancel
- Print | Imprimer | Stampare | Drucken | Imprimir | Imprimir

	<p>Ready for manual feed. Load paper, press print. French Ready for manual feed. Load paper, press print. Italian Ready for manual feed. Load paper, press print. German Ready for manual feed. Load paper, press print. Spanish Ready for manual feed. Load paper, press print. British Portuguese Ready for manual feed. Load paper. Press print.</p>
--	--

	<p>Two quick blinks: toner low French Two quick blinks: toner low Italian Two quick blinks: toner low German Two quick blinks: toner low Spanish Two quick blinks: toner low British Portuguese Two quick blinks: toner low</p>
--	--

	<p>Load paper French Load paper Italian Load paper German Load paper Spanish Load paper British Portuguese Load paper</p>
--	--

	<p>Cover open or cartridge not seated French Cover open or cartridge not seated Italian Cover open or cartridge not seated German Cover open or cartridge not seated Spanish Cover open or cartridge not seated British Portuguese Cover open or cartridge not seated</p>
--	--

	<p>Remove jam French Remove jam Italian Remove jam German Remove jam Spanish Remove jam British Portuguese Remove jam</p>
--	--

	<p>Blinks: out of memory French Blinks: out of memory Italian Blinks: out of memory German Blinks: out of memory Spanish Blinks: out of memory British Portuguese Blinks: out of memory</p>
--	--

	<p>Alternating blinks: output tray full French Alternating blinks: output tray full Italian Alternating blinks: output tray full German Alternating blinks: output tray full Spanish Alternating blinks: output tray full British Portuguese Alternating blinks: output tray full</p>
--	--

	<p>All blink: system error. Restart printer. French All blink: system error. Restart printer. Italian All blink: system error. Restart printer. German All blink: system error. Restart printer. All blink: system error. Restart printer. British Portuguese All blink: system error. Restart printer.</p>
--	--

www.xerox.com/officeprinting/

170mm

175mm