

Waste Cartridge • Bac de récupération • Contenitore residui • Sammelbehälter
 Cartucho de residuos • Cartutx de residus • Cartucho de resíduos • Afvalcontainer • Spillkassett
 Avfallsbeholder • Beholder til brugt toner • Hukkavärikasetti • Сборник отходов
 Odpadní nádobka • Wkład odpadów • Hulladékgyűjtő • Cartuş de toner rezidual • Atık Kartuşu
 Περιέκτης υπολειμμάτων

Xerox® Phaser® 6600 / Xerox® VersaLink™ C400

Color Printer • Imprimante couleur • Stampante a colori • Farbdrucker • Impressora de color • Impressora de color
 Impressora em cores • Kleurenprinter • Färgskrivare • Fargeskriver • Farveprinter • Väritulostin • Цветной принтер
 Barevná tiskárna • Drukarka kolorowa • Színes nyomtatók • Imprimantă color • Renkli Yazıcı • Έγχρωμος εκτυπωτής

Xerox® WorkCentre® 6605 / 6655 / Xerox® VersaLink™ C405

Color Multifunction Printer • Imprimante multifonctions couleur • Stampante multifunzione a colori • Farb-Multifunktionsdrucker
 Impresora multifunción de color • Impressora multifunció d'impressió en color • Impressora multifuncional em cores
 Multifunctionele kleurenprinter • Flerfunktionsskrivare (färg) • Flerfunktjonell fargeskriver • Multifunktionel farveprinter
 Värimonitoimitulostin • Многофункциональный цветной принтер • Barevná multifunkční tiskárna • Kolorowa drukarka wielofunkcyjna
 Színes többfunkciós nyomtató • Echipament multifuncțional color • Renkli Çok Fonksiyonlu Yazıcı • Έγχρωμος πολυλειτουργικός εκτυπωτής



See the instructional video at
www.xerox.com/office/6600support
www.xerox.com/office/WC6605support
www.xerox.com/office/WC6655support





Xerox® Phaser® 6600

Xerox® WorkCentre® 6605

Xerox® WorkCentre® 6655


Xerox® VersaLink™ C400

Xerox® VersaLink™ C405




3

3.1





3.2




4


4.1



4.2



4.3



5

