

Drum Cartridge • Module photorécepteur • Cartuccia fotoricettore • Trommeleinheit • Cartucho del cilindro
 Cartutx de tambor • Cartucho de fotorreceptor • Afdrukmodule • Tromkassett • Trommelkassett • Tromlemodul
 Rumpukasetti • Принт-картридж • Tisková jednotka • Wkład bębna • Dobkazetta • Cartuş cilindru • Tambur Kartuşu
 Φύσιγγα τυμπάνου • خرطوشة الأسطوانة

Xerox® VersaLink® C500 / C600

Color Printer • Imprimante couleur • Stampante a colori • Farbdrucker • Impresora de color • Impressora de color • Impressora em cores • Kleurenprinter
 Färgskrivare • Fargeskriver • Farveprinter • Väritulostin • Цветной принтер • Barevná tiskárna • Drukarka kolorowa • Színes nyomtató • Imprimantă color
 Renkli Yazıcı • Έγχρωμος εκτυπωτής • خرطوشة الأسطوانة

Xerox® VersaLink® C505 / C605


Color Multifunction Printer • Imprimante multifonction couleur • Stampante multifunzione a colori • Farbmultifunktionsdrucker • Equipo multifunción de color
 Impressora multifuncional d'impressió en color • Impressora multifuncional em cores • Multifunctionele kleurenprinter • Flerfunktionsskrivare med färg
 Flerfunktions fargeskriver • Multifunktionel farveprinter • Värimonitoimitulostin • Многофункциональное цветное устройство • Barevná multifunkční tiskárna
 Wielofunkcyjna drukarka kolorowa • Színes többfunkciós nyomtató • Imprimantă multifuncțională color • Renkli Çok İşlevli Yazıcı
 Έγχρωμος πολυλειτουργικός εκτυπωτής • طابعة بالألوان متعددة الوظائف




Xerox® VersaLink™ C500
 Xerox® VersaLink™ C600




Xerox® VersaLink™ C505
 Xerox® VersaLink™ C605




Xerox® VersaLink™ C605




4




4.2




5




6




7





7.2





8




8.1



8.2





8.3




9

9




10

10.1



10.2



11

