

Xerox® WorkCentre® 5800/5800i Series Printer Symbols

Symbol	Description
<u>^</u>	Warning: Indicates a hazard that can cause serious injury or death if not avoided.
	Hot Warning: Hot surface on or in the printer. Use caution to avoid personal injury.
	Laser Warning: This symbol indicates a laser is being used and alerts the user to refer to the appropriate safety information.
	Pinch Hazard: This warning symbol alerts users to areas where there is the possibility of personal injury.
0	Caution: Indicates a mandatory action to take to avoid damage to the property.
	Do not touch the part or area of the printer.
	Do not touch the part or area of the printer.
	Do not expose the drum cartridges to direct sunlight.
	Do not burn the item.
	Do not burn the toner cartridges.
	Do not burn the drum cartridges.
	Do not burn the waste cartridge.

Symbol	Description
	Pinch Hazard: To avoid personal injury, use caution in this area.
	To avoid lines on the output, ensure that original documents are loaded correctly in the document feeder.
	To ensure optimum print quality, open the document feeder and inspect the Constant Velocity Transport (CVT) glass for dirt and debris contamination.
	Contamination on the Constant Velocity Transport (CVT) glass.
	Clean the Constant Velocity Transport (CVT) glass with a clean cloth as indicated.
	After cleaning the Constant Velocity Transport (CVT) glass, it is clear of contamination.
♥ ②	Hot surface. Wait for the indicated time before handling.
	On
0	Off
<u>ර</u>	Standby

Symbol	Description
(1)	Ground/Common/Earth Terminal
	Do not use paper attached with staples or any form of binding clip.
	Do not use folded, creased, curled, or wrinkled paper.
	Do not load or use inkjet paper.
	Do not use transparencies or overhead projector sheets.
	Do not reload paper previously printed on or used.
	Do not use postcards.
	Do not use envelopes.
6	Do not use envelopes.
	Do not copy money.
	Add paper or media.
↓ MAX	Do not load paper in the tray above the MAX line.
T MAX T	Maximum Paper Level Do not use paper attached with staples or any form of binding clip.

Symbol	Description
	Load original documents face up in the document feeder in the direction of the arrow as indicated.
% √	Paper Jam
8	Lock
ð	Unlock
0	Paper Clip
*	Cooling
D	Elapsed Time
	Supply Paper
	Supply Paper Face Down
	1-Sided Original
	Hole-punched Paper
	Transparency
	Load letterhead face up.

Symbol	Description
	Load letterhead face down.
	Load labels face down.
•	USB Universal Serial Bus
움	LAN Local Area Network
&	Telephone Line
	Weight
⊚	Start Button
♥ ← ©	Stop Button
₹′	Pause Printing Button
©	Log In/Out Button
?	Help Button
岀	Services Home Button
	Services Button
fil	Job Status Button
i	Printer Status Button
	Language Button

Symbol	Description
3 &	
Ø	Power Saver Button
CA	All Clear Button
DII	Dial Pause Button
EHC	Eurasia Economic Community
	This item can be recycled.

