

Updating the Printer Software

When Xerox releases an updated version of printer software or firmware, you can update your printer to incorporate the new fixes and improvements.

Updating the Software

Before you begin

- Determine the current software version of your printer.
- Download the latest software update file in **.bin** format from the drivers and downloads page for your specific printer.

To determine the currently installed software version:

1. In CentreWare IS, click **Properties > General Setup > Configuration**.
2. Scroll down to **Software** to verify the software version.

To update the software:

1. In CentreWare IS, click **Properties > Services > Machine Software > Upgrades**.
2. Under **Upgrades** select **Enabled**.
3. Click **Apply**.
4. Refresh you browser and navigate to **Properties > Services > Machine Software > Manual Upgrade**.
5. Under **Manual Upgrade**, click **Browse** to locate and select the software upgrade file in **.bin** format.
6. Click **Open**.
7. Click **Install Software**.
The file is sent to the printer. Once the software is installed, the printer restarts.
8. Check the configuration report to verify that the software has updated.