Firmware Installation Instructions

Overview

The purpose of this document is to define the procedures on downloading device firmware via the device's Embedded Web Server.

Supported Products:

Xerox® B210 Printer

Xerox® B205Multifunction Printers

Xerox® B215 Multifunction Printers

Installation Instructions

Before updating, please read the important information below.

Manual upgrade using Internet Services

This section provides instructions to upgrade machine software over the network via Xerox CentreWare Internet Services (CWIS).

IMPORTANT: Print a new Configuration Report immediately before upgrading firmware. For instructions, see the User Guide at www.support.xerox.com.

Ensure that the machine is online before continuing. TCP/IP and HTTP protocols must be enabled on the machine so that the machine web browser can be accessed. Obtain the IP address of the machine you want to upgrade from the Configuration Report.

Upgrade Steps:

- 1. Open a web browser from your Workstation.
- 2. Enter the IP Address of the machine in the Address bar and select [Enter].
- 3. Verify that Firmware Upgrade is enabled:
 - a) Click on the [Properties] tab.
 - b) Click on [Maintenance] on the left
 - c) Click on [Upgrade Management] on the left
 - d) If prompted to login, enter the Admin ID and Password.
 - e) Check the Enable checkbox for Upgrades and click OK in the window that pops up.
- 4. Click on [Firmware Upgrade] on the left
- 5. Click on the [Choose File] or [Browse] button
- 6. Locate and select the software upgrade file obtained earlier. The firmware file will have an extension of .hd.
- 7. Click [Install Firmware].
- 8. Click [OK] to start the install process.

Note: Software Installation will begin several minutes after the software file has been submitted to the machine. Once Installation has begun all Internet Services from this machine will be lost, including the Web User Interface.

Once the download is complete, print a Configuration Report to verify the firmware version. <end>